









DREHKLEMMHALTER AUSSENBEARBEITUNG



Artikel-Nr.	L	f	h=h1	b	kg						
SEL 1010 H11	100	11	10	10	0,100	11 EL_	S11	T8	-	-	-
SEL 1212 F16	80	16	12	12	0,105	16 EL_	S16	T10	AI16	-	A16
SEL 1616 H16	100	16	16	16	0,210	16 EL_	S16	T10	AI16	-	A16
SEL 2020 K16	125	20	20	20	0,400	16 EL_	S16	T10	AI16	-	A16
SEL 2525 M16	150	25	25	25	0,745	16 EL_	S16	T10	AI16	-	A16
SEL 3232 P16	170	32	32	32	1,720	16 EL_	S16	T10	AI16	-	A16
SEL 2525 M22	150	25	25	25	0,735	22 EL_	S22	T20	AI22	-	A22
SEL 3232 P22	170	32	32	32	1,353	22 EL_	S22	T20	AI22	-	A22
SEL 2525 M27	150	25	25	25	0,790	27 EL_	S27	T25	AI27	-	A27
SEL 3232 P27	170	32	32	32	1,300	27 EL_	S27	T25	AI27	-	A27
SER 0808 H11	100	11	8	8	0,070	11 ER_	S11	T8	-	-	-
SER 1010 H11	100	11	10	10	0,095	11 ER_	S11	T8	-	-	-
SER 1212 F16	80	16	12	12	0,105	16 ER_	S16	T10	-	AE16	A16
SER 1616 H16	100	16	16	16	0,210	16 ER_	S16	T10	-	AE16	A16
SER 2020 K16	125	20	20	20	0,400	16 ER_	S16	T10	-	AE16	A16
SER 2525 M16	150	25	25	25	0,742	16 ER_	S16	T10	-	AE16	A16
SER 3232 P16	170	32	32	32	1,350	16 ER_	S16	T10	-	AE16	A16
SER 2525 M22	150	25	25	25	0,735	22 ER_	S22	T20	-	AE22	A22
SER 3232 P22	170	32	32	32	1,355	22 ER_	S22	T20	-	AE22	A22
SER 2525 M27	150	25	25	25	0,800	27 ER_	S27	T25	-	AE27	A27
SER 3232 P27	170	32	32	32	1,370	27 ER_	S27	T25	-	AE27	A27
SER 4040 R27	200	40	40	40	1,300	27 ER_	S27	T25	-	AE27	A27

① = Spannschraube ② = Schlüssel ③ = Unterlegplatte ④ = Unterlegplatte ⑤ = Spannschraube

DREHKLEMMHALTER AUSSENBEARBEITUNG




Artikel-Nr.	L	f	h=h1	b	kg						
SEL 2525 M22U	150	28	25	25	0,800	22 UEL_	S22	T20	AI22U	-	A22
SEL 2525 M27U	150	32	25	32	0,800	27 UEL_	S27	T25	AI27U	-	A27
SEL 3232 P27U	170	32	32	32	1,400	27 UEL_	S27	T25	AI27U	-	A27
SER 2525 M22U	150	28	25	25	0,800	22 UER_	S22	T20	-	AE22U	A22
SER 3232 P22U	170	32	32	32	1,325	22 UER_	S22	T20	-	AE22U	A22
SER 2525 M27U	150	32	25	32	0,800	27 UER_	S27	T25	-	AE27U	A27
SER 3232 P27U	170	32	32	32	1,320	27 UER_	S27	T25	-	AE27U	A27

① = Spanschraube ② = Schlüssel ③ = Unterlegplatte ④ = Unterlegplatte ⑤ = Spanschraube




BOHRSTANGEN INNENBEARBEITUNG LINKS



Artikel-Nr.	D min.	d	L	L1	f	kg					
SIL 0005 H06	6,4	12	100	12	4,3		06 IL_	TS 20038I	T6	-	-
SIL 0007 K08	7,8	16	125	18	5,3	0,170	08 IL_	TS 20054I	T6	-	-
SIL 0010 H11	12	10	100	-	7,4	0,070	11 IL_	S11	T8	-	-
SIL 0010 K11	12	16	125	25	6,5	0,175	11 IL_	S11	T8	-	-
SIL 0013 L11	15	16	140	32	8,0	0,200	11 IL_	S11	T8	-	-
SIL 0013 M16	16	16	150	32	10,0	0,192	16 IL_	S 16S	T10	-	-
SIL 0016 P16	19	20	170	40	11,4	0,365	16 IL_	S 16S	T10	-	-
SIL 0020 P16	24	20	170	-	13,4	0,390	16 IL_	S16	T10	AE16	A16
SIL 0025 R16	29	25	200	-	16,3	0,728	16 IL_	S16	T10	AE16	A16
SIL 0032 S16	36	32	250	-	19,6	1,435	16 IL_	S16	T10	AE16	A16
SIL 0040 T16	44	40	300	-	23,8	2,670	16 IL_	S16	T10	AE16	A16
SIL 0020 P22	24	20	170	-	13,0	0,410	22 IL_	S 22S	T20	-	-
SIL 0025 R22	29	25	200	-	17,2	0,730	22 IL_	S22	T20	AE22	A22
SIL 0032 S22	38	32	250	-	21,5	1,440	22 IL_	S22	T20	AE22	A22
SIL 0040 T22	46	40	300	-	25,8	2,675	22 IL_	S22	T20	AE22	A22
SIL 0032 S27	40	32	250	-	22,4	1,100	27 IL_	S27	T25	AE27	A27
SIL 0040 T27	48	40	300	-	26,4		27 IL_	S27	T25	AE27	A27
SIL 0050 U27	58	50	350	-	31,4		27 IL_	S27	T25	AE27	A27

① = Spannschraube ② = Schlüssel ③ = Unterlegplatte ④ = Spannschraube

BOHRSTANGEN INNENBEARBEITUNG RECHTS




Artikel-Nr.	D min.	d	L	L1	f	kg					
SIR 0005 H06	6,4	12	100	12	4,3		06 IR_	TS 20038I	T6	-	-
SIR 0007 K08	7,8	16	125	18	5,3	0,185	08 IR_	TS 20054I	T6	-	-
SIR 0010 H11	12	10	100	-	7,4	0,070	11 IR_	S11	T8	-	-
SIR 0010 K11	12	16	125	25	6,5	0,175	11 IR_	S11	T8	-	-
SIR 0013 L11	15	16	140	32	8,0	0,205	11 IR_	S11	T8	-	-
SIR 0013 M16	16	16	150	32	10,0	0,220	16 IR_	S 16S	T10	-	-
SIR 0016 P16	19	20	170	40	11,4	0,370	16 IR_	S 16S	T10	-	-
SIR 0020 P16	24	20	170	-	13,4	0,400	16 IR_	S16	T10	AI16	A16
SIR 0025 R16	29	25	200	-	16,3	0,735	16 IR_	S16	T10	AI16	A16
SIR 0032 S16	36	32	250	-	19,6	1,460	16 IR_	S16	T10	AI16	A16
SIR 0040 T16	44	40	300	-	23,8	2,720	16 IR_	S16	T10	AI16	A16
SIR 0020 P22	24	20	170	-	13,0	0,405	22 IR_	S 22S	T20	-	-
SIR 0025 R22	29	25	200	-	17,2	0,740	22 IR_	S22	T20	AI22	A22
SIR 0032 S22	38	32	250	-	21,5	1,460	22 IR_	S22	T20	AI22	A22
SIR 0040 T22	46	40	300	-	25,8	2,735	22 IR_	S22	T20	AI22	A22
SIR 0032 S27	40	32	250	-	22,4	1,480	27 IR_	S27	T25	AI27	A27
SIR 0040 T27	48	40	300	-	26,4	2,730	27 IR_	S27	T25	AI27	A27
SIR 0050 U27	58	50	350	-	31,4	4,995	27 IR_	S27	T25	AI27	A27
SIR 0060 V27	68	60	400	-	36,4		27 IR_	S27	T25	AI27	A27

① = Spannschraube ② = Schlüssel ③ = Unterlegplatte ④ = Spannschraube



TTHREAD SIR/L_U

BOHRSTANGEN INNENBEARBEITUNG FÜR U-TYP WENDESCHNEIDPLATTEN




Artikel-Nr.	D min.	d	L	L1	f	kg						
SIL 0008 K08U	9,0	16	125	21	6,4	0,050	08 UIL_	TS 20054I	T 6	-	-	-
SIL 0032 S22U	38	32	250	-	25,5	1,500	22 UIL_	S22	T20	-	AE22U	A22
SIL 0040 T22U	46	40	300	-	29,5	3,130	22 UIL_	S22	T20	-	AE22U	A22
SIR 0008 K08U	9,0	16	125	21	6,4	0,175	08 UIR_	TS 20054I	T 6	-	-	-
SIR 0032 S22U	38	32	250	-	25,5	1,455	22 UIR_	S22	T20	AI22U	-	A22
SIR 0032 S27U	40	32	250	-	24,7	1,480	27 UIR_	S27	T25	AI27U	-	A27
SIR 0050 U27U	58	50	350	-	34,3	4,900	27 UIR_	S27	T25	AI27U	-	A27

① = Spannschraube ② = Schlüssel ③ = Unterlegplatte ④ = Unterlegplatte ⑤ = Spannschraube

TMODULAR DTC-D_SIL/R

MODULARER GEWINDEKOPF MIT SCHRAUBENKLEMMUNG FÜR ANTIVIBRATIONSBOHRSTANGE



Artikel-Nr.	D min.	dw	L	f	kg					
DTC-D25-SIL-16	29	25	26	16,2	0,092	✓	16 IL_	S16	A16	AI16
DTC-D32-SIL-16	36	32	27	19,7	0,137	✓	16 IL_	S16	A16	AI16
DTC-D40-SIL-16	44	40	30	23,7	0,213	✓	16 IL_	S16	A16	AI16
DTC-D32-SIL-22	38	32	32	21,6	0,151	✓	22 IL_	S22	A22	AI22
DTC-D40-SIL-22	46	40	38	25,6	0,252	✓	22 IL_	S22	A22	AI22
DTC-D25-SIR-16	29	25	26	16,2	0,092	✓	16 IR_	S16	A16	AE16
DTC-D32-SIR-16	36	32	27	19,7	0,137	✓	16 IR_	S16	A16	AE16
DTC-D40-SIR-16	44	40	30	23,7	0,213	✓	16 IR_	S16	A16	AE16
DTC-D32-SIR-22	38	32	32	21,6	0,151	✓	22 IR_	S22	A22	AE22
DTC-D40-SIR-22	46	40	38	25,6	0,252	✓	22 IR_	S22	A22	AE22

① = Spannschraube ② = Spannschraube ③ = Unterlegplatte

NOTIZEN

